

PN# 10931: Double Kayak Rack
Assembly and Mounting Instructions



Tools Required:

9/16" and 5/8" wrench/socket for hardware installation

Assembly Hardware:

- (4) M10 x 60mm - Fastens storage arms to vertical pipe supports
- (6) Patriot Docks vinyl pipe cap—blue
- (4) Velcro storage straps



Step #1

Mount the (4) storage arms to the (2) vertical support pipe by lining up the storage arms with the pre-drilled holes on the vertical support pipe. Secure the storage arms to the vertical support pipe using the (4) M10 x 60mm bolts and nuts.

Note: The Patriot Docks kayak rack DOES NOT INCLUDE brackets to install to a dock frame. The following brackets will be needed to finish installation.

Installing on Patriot Docks Truss Frame



PN# 10810: Steel Pipe Holder
Qty (2)

Installing on Patriot Docks Low-Pro Frame



PN# 10937: Steel Piling Sleeve
Qty (2)