

# Double Kayak Rack

Assembly Instructions

PN 10931

## RECOMMENDED TOOLS



Wrenches or sockets:  
M14 (or 9/16")  
M15 (or 5/8")



Cordless Drill



Work Gloves

	Part Number	Description	Qty.
A	10931-1	Kayak Horizontal	4
B	10931-2	Kayak Vertical	2
C	10823	Patriot Vinyl Pipe Caps	6
D	Strap	Nylon Velcro Strap	4
E	Hardware	M10x60 Bolt/Nut	4



# Double Kayak Rack

## Assembly Instructions

- 1 Mount the (4) Kayak Horizontals (A) to the (2) Kayak Verticals (B). Each Kayak Vertical pipe has two pre-drilled mounting holes for the Kayak Horizontal pipe. Line up the Kayak Horizontals with the pre-drilled holes, secure with M10x60mm bolt and nut.



- 2 Use Patriot Vinyl Pipe Cap (C) to cap all Kayak Rack Horizontals, and the top of both Kayak Verticals. The Nylon Velcro Strap is used to secure your Kayak to the Kayak Horizontal post.

### Installation Notes:

PN10931 Kayak Rack **does not include** mounting brackets. Patriot Docks offers mounting brackets for both styles of Patriot frames (PN10800 Patriot Truss Frame/PN10835 Patriot Low Pro Frame). When installing onto a Patriot Dock style frame mount the corresponding Patriot Docks frame, slip the Kayak Rack into the mounting bracket and tighten pinch bolts to secure Kayak Rack in place.

When installing without Patriot Docks mounting brackets, note the outside dimensions of the Kayak Rack Vertical is roughly 1.9" (48mm). When using a different mounting bracket ensure inside dimension is larger than the outside dimension of the vertical pipe.



**Installing on PN10800 Patriot Truss Frame** - PN10810 - Steel Post Bracket  
Requires Qty. (2)



**Installing on PN10835 Patriot Low Pro Frame** - PN10937 - Steel Low Pro Post Bracket  
Requires Qty. (2)

