

Deck Lockers

Assembly Instructions

Poly Deck Locker:
PN10867

RECOMMENDED TOOLS



Screwdriver
(Phillips & Flathead)



Work Gloves



Front



Back

	PN	Description	Qty.
A	10867-1	Plastic Base	4
B	10867-2	Plastic Tab	4
C		M4x6mm Stop Bolt	4
D		M4x16mm Self Tapping Screw	8



*PN10867 Poly Deck Lockers may come already assembled. Always check to ensure that the Plastic Tab (B) is correctly orientated on the Plastic Base (A).



- 1 Each Poly Deck Locker will consist of one Plastic Base (A), one Plastic Tab (B), one M4x6mm Stop Bolt (C), and two M4x16mm Self Tapping Screws (D) for mounting.

Begin by attaching the Plastic Tab (B) to the Plastic Base (A). Ensure the countersunk holes on the Plastic Base (A) are facing you when inserting the Plastic Tab (B). Twist Plastic Tab to lock the Base and Tab together. See image to the right for reference.



- 2 Install M4x6mm Screw (C) on Plastic Base (A). This will act as a Stop Bolt to ensure the Plastic Tab (B) can not separate from the Plastic Base (A).



3

Install assembled deck locker to the Poly Panel. Generally, install between the first and second boards on both sides of the Panel. Use M4x16mm Self Tapping Screws to secure the Deck Locker to the Poly Panel. Each Poly board will have a pre-drilled mounting hole. Once all Deck Lockers are installed, drop panel into frame, apply slight pressure to the area of the Deck Lock and use a Flat Head screwdriver to lock in place.

